



## How to set up Zebra roll printers on Windows/Chrome

### Before the installation make sure that:

- Your Flea Lover site is accessed via Chrome and you have at least 1 customer created.
- The roll printer model is Zebra GK420D, Zebra ZD220 (or similar).
- The roll printer is connected to the PC via. USB.
- The roll printer is turned on, and a roll of labels are inserted correctly – test this by pressing the “feed” button on top of the printer: a single blank label is produced by the printer.

### Driver installation:


1. Install the Zebra driver.

You probably received a driver when purchasing the printer – otherwise here is a link.

<https://www.zebra.com/gb/en/support-downloads/printers/desktop/gk420d.html#Tab-item-35c5e20f9f-tab>

Select the Windows Printer Driver


Make sure to check “Run the printer installation wizard” during the driver installation




2. Select “Install Printer”



3. Select the port corresponding to the printer model. (ZDesigner GK420d or ZDesigner ZD220 (ZPL))



4. Verify that the printer appears under “Printers & Scanners” and perform a test print (the printer only needs to respond to the test).





5. Set up label size:

Search “Printers & Scanners” in Windows →

“Printer Name” (“ZDesigner GK420d” or similar) →

“Manage” →

“Printing Preferences” →

“Options” →

“Size” →

Configure the “Label Size” *Width* and *Height* according to your label size.

If it does not fit, try increasing *Left* and *Right* in very small increments, until it fits.

ZDesigner GK420d Printing Preferences

Barcode Fonts      Command Fonts

Custom Commands    Import/Export settings    Tools    About

Options    Advanced Setup    Dithering    Stocks    Printer Memory

Settings

No. Of Copies:

Speed:  "/s

Darkness:

Stocks:

Paper Format

☐ cm     ☒ portrait

☐ mm    ☐ landscape

☒ inch    ☐ rotate 180°

Size

Width:

Height:

Unprintable Area

Left:     Top:

Right:     Bottom:

OK    Cancel    Apply    Help



## Setup in Flea Lover

It is not always necessary to perform a setup in Flea Lover. Therefore, a test print can be attempted first. Follow the instructions below:

Go to your system in Flea Lover and perform a test print by clicking **“Print Barcode”** for any customer.

A window should appear where labels can be printed. Before printing, it is important to first:

1. click **“More Settings”** and then set **“Margins”** to **“None”**.
2. Ensure **“Paper size”** is blank and not **“user defined”**.

You can now print by clicking **“Print”**.

Use the picture below as reference.

The screenshot displays a print setup window. On the left, a label template is shown with the text "kbjlu1000", "1", and "Pris:" followed by a horizontal line. Below the text is a barcode. On the right, the print settings are configured. The "Print" button is highlighted in blue. The settings include:

- Destination: ZDesigner GK420d
- Pages: All
- Copies: 1
- Layout: Portrait
- More settings (expanded):
  - Paper size: (blank)
  - Pages per sheet: 1
  - Margins: None
  - Scale: Default
  - Options: ☐ Background graphics

At the bottom right, there are "Print" and "Cancel" buttons.